




REMOVE SIDE CAPS
FROM HUBS FOR 20MM THRU AXLE
DH41SB, DH61SB, AH41SB, etc.



Step 1:
Insert 20mm alloy thru axle to side cap.



Step 2:
Jemmy side cap by 20mm alloy thru axle.